



Vendor: Zebra
Model: DS2208

Rev. A (18.04.2023)
Identifier: Zebra

1.		Factory Defaults	9.		Disable Keypad Emulation
2.		Enable Prefix / Suffix	10.	 <small>(*choose different country-code if needed)</small>	Country Germany*
3.		Set Prefix	11.		
4.		1	12.		
5.		0	13.	Optional Codes:	
6.		0	14.		Beeper Volume Low
7.		2	15.		Beeper Volume Medium
8.		Enable Identifier	16.		Beeper Volume High